

CONDENSED APPLICATION STEPS FOR:
ISO-FLEX ONE AND DONE BALCONY COATING SYSTEM

<u>STEP</u>	<u>METHOD OF APPLICATION</u>	<u>COMPONENT</u>	<u>APPROX COVERAGE</u>
Preparation	Patch and repair where needed. Route cracks over 1/16". Pressure wash Concrete @ 3,500 PSI min., with spinner tip Caulk joints and cracks.	Primer 10 880GB/881	
Note: The Iso-Flex One and Done Coating System utilizes a 2-component aliphatic urethane with adhesion promoter and incorporated 16 mesh synthetic aggregate. The One and Done is applied over the pressure washed and dry concrete surface.			
Wear Course	1/4" notched squeegee followed by backrolling-1/2" to 3/4" nap roller	One and Done Balcony 35 wet/35 dry mils	45 sq ft/gallon

TOTAL MILS 35 mils