

CONDENSED APPLICATION STEPS FOR
ISO-FLEX ONE AND DONE DECK COATING SYSTEM

<u>STEP</u>	<u>METHOD OF APPLICATION</u>	<u>COMPONENT</u>	<u>APPROX COVERAGE</u>
Preparation	Patch and repair where needed. Route cracks over 1/16". Shot blast concrete. Caulk joints and cracks.	880GB/881	
Detail Coat (Based on Manufacturer Recommendations)	A 4" wide detail strip of primer and base coat are applied over all cracks less than 1/16" wide, control joints and cold joints	See primers below 750 Base Coat Or 780 Base Coat	240 lf/gallon
Primer	Roll or Spray apply	Primer 750 Primer 757	300 sq. ft/gallon 300 sq. ft/gallon
Wear Course	1/4" notched squeegee followed by back rolling with a 1/2" to 3/4" nap roller	Iso-Flex One and Done (Mix only full matched units) 45 wet/45 dry mils	35 sq ft/gallon
TOTAL MILS		45 mils	