

## Iso-Flex Factory Molded Expansion Joint Floor-to-Floor Installation Procedures

- A.** The expansion joint opening shall be a consistent width along its entire length, or be within the established width dimensions for the specified seal for the particular project. Refer to LymTal International Dwg No. 1054 (Blockout Type) or Dwg 1203 (Surface Type) for specific sizing information. The concrete blockout edges must be clean and sound. The expansion joint opening should be sandblasted to remove any laitance or material that would inhibit the bond of the sealant. Additionally, sandblasting will provide an adequate surface profile to which the sealant will bond. Should sandblasting not be possible, the joint faces must be ground with a coarse disc grinder to produce an abraded surface. Be careful not to polish the surface as this could cause failure of the sealant. Any repair materials used should be allowed to fully cure per manufacturer's recommendations before the installation is begun.
- B.** Blow the joint clean to remove any dust, or other contamination. Be certain that any high spots have been eliminated to ensure that the installed joints are slightly recessed from the concrete surface.
- C.** Roll out the Premold rubber along the side of the expansion joint blockout. Abrade the beveled edges of the Premold Seal by using a wire brush. Then wipe the surface clean with a solvent such as toluene. Note that the Premold can shrink once unrolled and allowed to relax. Do not make any final cuts until the rubber has had time to relax and to shrink to its normal length.
- D.** Wipe aluminum plates with Methyl Acetate solvent to remove any dirt or oils. Using either a brush or rag, apply a thin film of Primer #42 to the aluminum plate. Do not over prime. For maximum adhesion sandblasting or grinding of the plate is recommended prior to the solvent wipe. Let the primer dry for ½ to 2 hours.
- Note:** Proper installation requires that the 980 Nosing achieve a good bond to the ¾ inch depth and the base of the concrete blockout. Therefore, care should be taken not to contaminate the concrete during the bedding procedure that follows.
- E.** Mix parts A & B of the prepackaged Primer #10. Be sure to stir the combined components for 2 minutes until completely combined into an amber liquid. Apply Primer #10 to the concrete surfaces and the beveled edge of the Premold using a disposable brush. Apply just enough to wet out the surface. It is important that the Primer #10 be allowed to completely dry for a minimum of one and one half hours. It is important that the primer is completely dry and tack free before installing 980 Nosing. Following the one and one half hour minimum drying period there is a four-hour window of application. After four hours the surface must be re-primed. (Cool temperatures will extend the time necessary for the primer to become dry and tack free)

- F.** Thoroughly mix the two components of Iso-Flex 881 bedding. Using a bulk caulking gun ribbon the 881 bedding sealant on each side of the stem opening of the joint. The bedding is intended to level the blockout so that the plates will rest smooth and flat. Bedding must fully support the plate and provide for anticipated movement.
- G.** On one side of the stem opening lay out a precut piece of polyethylene on to the fresh bedding to act as a bond breaker. The polyethylene sheet should not extend into the area that will receive the 980 nosing.
- H.** Bed the aluminum plate, primed side down, into the bedding sealant. Be certain to leave 1/8" to 1/4" spacing between each plate section as you progress down the length of the joint Utilize a section of Premold as a template to set the plates to a proper depth. The temperature determines placement of plates within the blockout at the time of installation, and by the expected annual movement rating.
- I.** Tape visqueen over the top of the aluminum plates to keep the plates free floating under the Premold.
- J.** Place the premolded seal into the blockout making sure the seal is centered over the joint gap. Tape edges of the Premold seal and the concrete at the edge of the blockout to protect from over spill of the primer and sealant.
- K.** Apply Primer #10 to the concrete surfaces and the beveled edge of the Premold using a disposable brush. Apply just enough to wet out the surface. It is important that the Primer #10 be allowed to completely dry for a minimum of one and one half hours. It is important that the primer is completely dry and tack free before installing 980 Nosing. Following the one and one half hour minimum drying period there is a four-hour window of application. After four hours the surface must be re-primed. (Cool temperatures will extend the time necessary for the primer to become dry and tack free)
- L.** Thoroughly mix the two components of Iso-Flex 980 Nosing, and caulk the expansion joint into position. Tool to a smooth finish. Note that the Iso-Flex 980 Nosing has a relatively short work life, ensuring full cure and bond strength before movement. **Note:** Caulking alternately from one side to the other will avoid movement of the seal laterally in the blockout.
- M.** All butt joints must be spliced by properly grinding of the Premold seal. The splice is then primed, and then caulked tightly per Detail 2156-00 or 2160-00 with Iso-Flex 830 or 881 sealant, bonding one piece of Premold to the other. This operation can be done while the Iso-Flex 980 Nosing, is being installed.
- N.** Pull the protective tape from the Premold and the concrete and dispose of properly.
- O.** Open to traffic after 24 hours of cure.

Rev 04/18